



Clamp Base




Desk Knobs Clamp Base




Grommet Base





Desk Monitor 1 - Arm series




2 - Arms series



4 - Arms series




Wall Mount




1 - Arm series




2 - Arms series



4 - Arms series



Lift - up & down




Torque Adjust

Lift - up & down (for ARM Hold)
 Torque Adjust
 1. Tension of spring can be adjusted per user's preference.
 2. DO NOT OVERTIGHTEN the Fastener. Over tightening the fastener may result your LCD ARM in damage.


Tilt - Backward & Forward



Arm Swing Adjust Swivel & Rotate (Pivot)




Cable Management



Physical Dimensions (mm)



Height Adjust




Tilt




Notice

1. Please check the mount pattern of existing VESA plate to be compatible with subject keyboard or laptop plate/adaptors.
 2. It's highly recommended to have pivot fixed before subject plate/adaptors to be installed.
 3. Consult the stores you bought the goods or your distributor if any question remained.



Physical Dimensions (mm)



Height Adjust



Tilt



Notice

1. Please check the mount pattern of existing VESA plate to be compatible with subject keyboard or laptop plate/adaptors.
 2. It's highly recommended to have pivot fixed before subject plate/adaptors to be installed.
 3. Consult the stores you bought the goods or your distributor if any question remained.